

**5,000 MILE PM SCHEDULE
(BEGINNING WITH VEHICLES ISSUED IN 2008)**

5,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
10,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
15,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS REPLACE FUEL FILTER CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
20,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
25,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
30,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK BRAKE LININGS REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK TIRE PRESSURE AND ROTATE TIRES
35,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
40,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
45,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS REPLACE FUEL FILTER CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
50,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS SERVICE TRANSMISSION AND REPLACE FILTER CHECK TIRE PRESSURE AND ROTATE TIRES

55,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
60,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK BRAKE LININGS REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK TIRE PRESSURE AND ROTATE TIRES
65,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
70,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
75,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS REPLACE FUEL FILTER CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
80,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
85,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
90,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK BRAKE LININGS REPLACE SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK TIRE PRESSURE AND ROTATE TIRES
95,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
100,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS SERVICE TRANSMISSION AND REPLACE FILTER CHECK TIRE PRESSURE AND ROTATE TIRES

5,000 MILE PM SCHEDULE
(BEGINNING WITH VEHICLES ISSUED IN 2008)

105,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS REPLACE FUEL FILTER CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
110,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS .CHECK TIRE PRESSURE AND ROTATE TIRES
115,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
120,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK BRAKE LININGS REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTER CHECK TIRE PRESSURE AND ROTATE TIRES
125,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
130,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
135,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS REPLACE FUEL FILTER CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
140,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
145,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK TIRE PRESSURE AND ROTATE TIRES
150,000	CHANGE OIL AND FILTER LUBE CHASSIS AS REQUIRED CHECK AND FILL ALL FLUID LEVELS CHECK BRAKE LININGS REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS SERVICE TRANSMISSION AND REPLACE FILTER CHECK TIRE PRESSURE AND ROTATE TIRES